


Typical "Washworld" Equipment List

| No. | Description | Comments |
|-----|---|---|
| 01 | Hanging Clearance Sign | Ground Mount Free Standing Shown or Hung Inside Overhead Door Opening |
| 02 | Cash / Code Acceptor | Manufacturer, Style and Options Vary |
| 03 | Entrance Wait/Go Sign | Wall Mounts To Face Of Building Near Location Shown |
| 04 | Menu Sign | Wall Mount or Leg Mount, Either Horizontal or Vertical Style |
| 05 | Joystick Control Box & System Stop Button | Wall Mounts To Face Of Building Near Location Shown |
| 06 | Bay Junction Box | Wall Mounts High Inside Wash Bay Typically Near Location Shown |
| 07 | Under Body Photo Eyes | Typically Wall Mount Inside Bay As Shown |
| 08 | Under Body Wash Manifold | Either Surface Mounted Where Shown Or Requires Notch In Floor For Flush Mounting |
| 09 | Wall Mount & Rails | Wall Mount Kits Vary By Width Of Bay, Typically 26' Rails As Shown |
| 10 | Razor Wash Carriage | Wash Carriage Shown At "Home" Position In Wash Bay For Reference |
| 11 | 7 Panel Service Confirmation & Directional Sign | Wall Mounts Inside Bay On Drivers Side Near Location Shown |
| 12 | Interior Wall Mount 45 HP Drying System | Dryer Mounts To Cross Beam Supported On Each End From Wall Mounted Brackets |
| 13 | Dryer Motor Starter Panel | Can Mount Either In Wash Bay or Equipment Room As Shown |
| 14 | Pumping Station | Floor Stand To Be Located In Equipment Room Typically Near Bay Center Line |
| 15 | Pump Motor Starter Panel | Comes Pre-Wired To Pump Station And Must Wall Mount Nearby |
| 16 | Ultimate Control Cabinet "UCC" | Wall Mount Within 6' Of Pump Station (Comes pre-wired to pump station) |
| 17 | RO (Spot Free) System | Floor Stand To Be Located Where Space Permits, Typically Near Storage Tank |
| 18 | RO Holding Tank | Sizes Vary, Typically Located To Provide head Pressure For Re-pressurization Pump |
| 19 | RO Re-pressurization Pump | Typically Mounts Low on Wall Or To Floor Near RO Tank |
| 20 | Water Softening System | Sizes Vary Dramatically, System Shown Is Twin Alternating For Reference Only |
| 21 | Door Control Entrance Eyes And "J" Box (Not Shown) | Typically Wall Mount Low, Outside Entrance Door |
| 22 | Door Control Exit / Dryer Shut Off Eyes & "J" Box | Typically Wall Mount Low, Outside Exit Door |
| 23 | Dryer Image Package (Covers) | Shown With Image Package Covers On For Space Planning Purposes. |
| 24 | 240 V Conversion Kit (Not Shown) | Typically Wall Mounts Near UCC Cabinet |
| 25 | Wash Bay Reflectors or Floor Treadle | Shown With Blue Reflector Kit Floor Mounted, For Treadle See Owners Manual |
| 26 | Dryer Count Down Timer With Stand | Typically Mounts Outside Exit Door On Either Side Depending On Exit Arrangement |
| 27 | Roto Blaster (Not Shown) | Floor Mounts Directly In Line With Under Carriage Manifold |
| 28 | HP Manifold Assembly (Not Shown) | Can Be Located Inside Wash Bay Or In equipment Room Or Attic Area |
| 29 | Ultimate Door Control Loop Or Photo Eyes (Field Locate) | Typically Use In-Ground Loop On New Construction And Photo Eyes For Existing |
| 30 | 12 kw Electric Pre-Soak Heater (1 per automatic) | Wall Mounts Near Pumping Station (Not Shown) |
| 31 | Triple Foam / Flex Pass Cold Weather Package Weep Panel | Wall Mounts Near Pumping Station (Not Shown) |
| 32 | On Demand Natural Gas Wall Hung Water Heater | Wall Mounts Near Pumping Station |



**Preliminary
NOT APPROVED
FOR CONSTRUCTION**

Typical Washworld 1 Bay Automatic

W/ 1 Self Service Bay

Revised July 28, 2012

